A4LD C3, 4R44E/55E, 5R55E

PART NUMBER 56532-01K


Reverse Servo Sleeve Kit

56532-01K

1 Servo Sleeve 1 Back-up Ring 1 O-Ring




Note: Machining of the servo is required



Installation Instructions

- 1. Remove the servo piston from the transmission case.
- 2. Remove the two piston o-rings.
- 3. Remove the pin and springs.
- 4. Mount the piston in a lathe as shown in Figure 1.

Figure 1



- 1. Remove burrs
- 2. Break sharp edges .020" max.
- Always remove servo pin and spring.
 Any sediment trapped here can cause additional servo scoring/damage.



A4LD C3, 4R44E/55E, 5R55E

PART NUMBER 56532-01K

- 5. Turn the inner piston O.D. to the dimensions shown.
- 6. Install the o-rings and back-up ring as shown.
- 7. Check the fit of the piston and the sleeve.
- 8. Roughen up the surface of the bore with an abrasive pad or sandpaper (remove any high spots caused by scoring).
- 9. Clean the worn case bore and sleeve with solvent to remove any oil or debris.
- 10. Apply Loctite 609® or 660® around the sleeve.
- 11. Insert the sleeve in the case as shown in Figure 2.
- 12. Allow the adhesive time to cure.
- 13. Stake the sleeve in place as shown in figure 3.
- 14. Reassemble.

Figure 2




Figure 3

