**PART NUMBERS 72854-03K, -TL2** 

# **TCC Regulator Valve Kit**

#### 72854-03K

- 1 Sleeve
- 1 Valve
- 3 Springs
- 1 Washer
- 1 O-Ringed End Plug

#### 72854-TL2


2 Reamers

**Note:** Reamer tool kit **72854-TL2** us necessary to enlarge the bore to accept the sleeve and valve assembly.

Also Available:


#### 72754-01K

4T80-E Boost Valve Assembly



## **Wet Air Test**

- 1. Place a small amount of oil into the balance port. Follow with low air pressure. There should be minimal/no leakage past the end plug or past the valve spool and out the line port.
- 2. Place a small amount of oil into the TCC control port. Follow with low air pressure. There should be minimal/no leakage past the valve spool and out the exhaust port.
- 3. If there is excessive oil or air leakage, the valve bore should be enlarged and an oversized valve installed.





PART NUMBERS 72854-03K, -TL2

# **Reaming Instructions**

- 1. Remove all components from the bore.
- 2. Clean the valve body bore thoroughly in a solvent tank.
- 3. Securely clamp the valve body horizontally to the bench, making sure not to clamp directly over the bore to be reamed.
- 4. Soak the bore and reamer with cutting fluid (Tap Magic®, Mobilmet, etc.).
- 5. Place self-piloting reamer #1 into the bore, and ease forward until the cutting tip contacts the first bore to be reamed. (See photo)
- 6. Turn the reamer in a smooth and continuous clockwise motion, at 60-200 rpm. Continue reaming until the reamer bottoms in the bore.
- 7. Using low air pressure, blow the chips free prior to removing the reamer.
- 8. To remove the reamer, turn clockwise while slowly pulling outward on the reamer.
- 9. Remove any remaining debris from the bore with air pressure and clean in a solvent tank.
- 10. Repeat steps 4 through 9 using self-piloting reamer #2.



- 1. Never turn the reamer backward. This will dull the reamer.
- 2. Pushing forward on the reamer will result in poor surface finish and inadequate and sporadic material removal.
- 3. Never use a crescent wrench, ratchet or pliers to turn the reamer.
- 4. Clean the reamer after each use and store in its protective tube
- 5. A dull reamer will cut a smaller hole. Reamers can be sharpened. Actual life of a reamer before resharpening averages 50 to 70 bores, and depends on oil and turning process. Take the reamer to a professional tool sharpener for resharpening.

## **Installation Instructions**

- 1. Remove all components from the bore. Keep the OEM retainer and discard the valve, spring and end plug.
- 2. Ream the bore according to the instructions.
- 3. Push the sleeve into the bore, notched end first, until it bottoms in the bore (see photo on front page).
- 4. Push the valve into the installed sleeve, stem end facing out (see photo on front page).
- 5. Select ONE of the 2 longer and narrower springs per the following application, and place over the installed valve stem:
- For OEM TCC Apply (25psi cracking) use the **UNPAINTED** spring
- For firm TCC Apply (18psi cracking) and less slippage, use the WHITE spring
- 6. Install the washer so that it sits flush with the outer face of the installed sleeve.
- 7. Install the shorter and wider spring into the bore, over the valve stem and inner spring, flush with the washer.
- 8. Lubricate the o-ring with O-Lube, and install into the small groove on the end plug. Gently push the o-ringed end plug into the bore, recessed pocket facing inward, until the OEM retaining clip can be installed into the end plug.



